

RR580 Electric Wheelbarrow

Assembly of the RR580 Electric Wheelbarrow

Unfold tabs and open lid of crate. Crate sides can also be folded down.



Install handles on either side of control box

The handles will be located under the wheelbarrow frame



RR580 Electric Wheelbarrow

Tip the wheelbarrow forward onto its nose to install rear wheels

Use one of the pieces of foam in the crate to protect the front LED light



Wheelbarrow can be set down

Use a floor jack, or something to lift the front high enough to mount front wheels



RR580 Electric Wheelbarrow

Lift bucket onto the top of the wheelbarrow

You will be able to move it into place and slide the pin through

Secure the pin



Flip up the bucket and extend cylinder to help with installing the next pin



Pin has been installed



RR580 Electric Wheelbarrow

Mount your LED light onto the control panel

Assembly is finished, test all functions and charge battery fully

